


The Projection Lensmeter Operating Instruction



Contents

1 Characteristics and Uses of Device	1
2 Main Technical Indexes	2
3 Working Principle of Device	3
4 Description of Device Structure	4
4.1 Viewed from the Front	4
4.2 Viewed from the Side	6
4.3 Viewed from the Rear	7
5 Instruction of Operation	8
5.1 Before Measurement	8
5.1.1 Preparation	8
5.1.2 Putting Lens in Position	9
5.2 Measurement of Lens	10
5.2.1 Measurement of Spherical Lens	10
5.2.2 Measurement of Cylindrical Lens	10
5.2.3 Measurement of Bifocal Lens	12
5.2.4 Measurement of Prism Lens	13
5.2.5 Measurement of Hard Cornea Contact Lens	14
5.3 Calibration of Lens	15
5.3.1 Calibration of Spherical Lens	15
5.3.2 Calibration of Cylindrical Lens	15
5.3.3 Calibration of Prism Lens	15
5.3.4 Calibration of Optic Center of Assembled Two Lens	15
5.4 Storing Functions	16
5.5 Printing Data	16
5.6 Function of Automatic Stop	16
5.7 Setting Grade of Measurement	17